


## What's in the Box?

1. LCR Elite2 Portable LCR meter
2. Storage Box
3. USB Cable
4. Quick Start Guide
5. NIST Certificate

## Measurement Screen



## Switching to Menu Screen from Measurement Screen

To switch to menu screen during measurement, please hold the navigation button for half second or so until the main menu screen shows up.

## Menu Screen and Navigation

To switch menu options, please single click the navigation button. To select menu options, please hold the navigation button.



## Charging the Battery

The LCR Elite2 is powered by an internal lithium-ion polymer rechargeable battery. It can be charged by a computer or a USB power adapter (available separately).

## Power Off

The LCR Elite2 powers off automatically if neither a measurement is performed nor the navigation button is clicked for around 1 minute. To manually power off the meter, please select the "TURN OFF" option from main menu.


## Warranty

LCR Research warrants this product to be free from defects in materials and workmanship for a period of one (1) year from the shipment date. During the warranty period, LCR Research will, at its option, either repair or replace products that prove to be defective. Repaired or replaced products are warranted for the balance of the original warranty period.

This warranty does not cover normal wear and tear and scratches on surface or display. This warranty does not cover physical damage to the display, switch or button, electrical damage of the product due to high voltage or improper battery type. This warranty shall not apply to defects resulting from improper or inadequate maintenance by the buyer, buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

For more detailed information, please refer to the Warranty section in the LCR Elite2 User Manual.

## Menu Structure



### This device complies with the Class B of FCC Part15, Subpart B and IC ICES-003.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-3 (B)/NMB-3(B)

### Useful Information

LCR Research Website: [www.lcrresearch.com](http://www.lcrresearch.com)

LCR Elite2 User Manual: [www.lcrresearch.com/downloads](http://www.lcrresearch.com/downloads)